

|                            |                 |
|----------------------------|-----------------|
| <b>Article number</b>      | 4610089         |
| <b>Article designation</b> | Sealing section |

This sealing section is completely made of EPDM and has a steel insert. Because of the high bending radius of this sealing profile, it is easy to bend around corners. The rubber profile is easy to fasten and has two functions: protecting from sharp edges and sealing. It is temperature resistant from -40°C up to +100°C.

## General information

|                  |                    |
|------------------|--------------------|
| Assembly profile | EPDM quality ES 60 |
| Assembly bulb    | EPDM quality ES 06 |
| Assembly insert  | Steel 1.0347       |
| Clamping range   | 1-3 mm             |
| Colour           | Black              |

## Directives

|                              |           |
|------------------------------|-----------|
| Reach                        | Compliant |
| RoHS - RL 2002/95/EG (EC)    | Compliant |
| Altauto - RL 2000/53/EG (EC) | Compliant |

## Product image

