

Article number	461C057
Article designation	Sealing section

This sealing section is made of silicone and has a stainless steel insert. Because of the high bending radius of this sealing profile, it is easy to bend around corners. The profile is easy to fasten and has two functions: protecting from sharp edges and sealing. This protector is often used in food industries or in industries where silicone is required. It is temperature resistant from -60°C up to +180°C. It can briefly resist temperatures of 200°C.

General information

Assembly profile	Silicone
Assembly bulb	Silicone
Assembly insert	RVS 316
Clamping range	1-4 mm
Colour	Black

Directives

Reach	Compliant
RoHS - RL 2002/95/EG (EC)	Compliant
Altauto - RL 2000/53/EG (EC)	Compliant

Product image

