

STREAMO CRUISER NG SPECIFICATION SHEET

KEY POINTS

Flexible
flooring

Ease of
installation

Evercare surface
treatment

Modern semi-
directional pattern

Wear group
P

Application

- The flooring shall be especially designed for ships and offshore platforms interiors

Product construction

- The material shall be a 2mm thick homogeneous vinyl flooring available in sheets
 - ▶ The flooring shall be flexible for an easy installation using flash coving technique
- The joints shall be hot welded with round welding rods of 4mm diameter manufactured and supplied by the flooring manufacturer
 - ▶ The pattern of the material shall be semi-directional for a modern look
 - ▶ The wear group of the flooring material shall be Group P according to EN 649 to guarantee a good wear resistance

Surface treatment

- ▶ The flooring shall have a lifetime wax free surface treatment obtained by UV laser cross-linking process to ease the maintenance, reduce its costs and to limit the risk of micro-scratches

Safety

- The flooring shall have a R9 slip resistance according to DIN 51130 to reach a good compromise between safety of passengers/workers onboard and ease of maintenance

Regulation

- The flooring shall conform to the IMO requirements detailed in the Fire Test Protocol (parts 2 & 5)
- The flooring shall conform to the Marine Equipment Directive / US Coast Guard
- The Type Approval Certificate shall be recognized by Transport Canada
- The flooring shall conform to the SOLAS 74 Convention
- The manufacturer of the floor covering must be in possession of a valid quality systems certificate, showing compliance with ISO 9001

Environment

- The flooring shall comply with the guidelines for development of Inventory of Hazardous Materials Resolution MEPC 197 (62)
- The flooring shall be free from heavy metals (Lead, Cadmium, Barium, Tin, Chromium...).
- The flooring shall be free from DEHP plasticizer
- The flooring shall be free from any substance potentially subject to any REACH restrictions
- The manufacturer of the floor covering must be in possession of a valid ISO 14001 certificate
- The flooring shall have very low VOC emissions (< 10 µg/m³, after 28 days)